



Southeast Aerospace, Inc
1399 General Aviation Dr
Melbourne, Florida 32935 USA
sales@seaerospace.com
Tel: 321-255-9877
Fax: 321-255-9608
www.seaerospace.com

Bell 212 Capabilities List

Part Number	Model	Description	Capability
011-00280-10	GNS-430	GPS/Nav/Comm	Repair, Spares, Exchange
011-00504-00	GPS-400	GPS	Repair, Spares, Exchange
011-01057-00	GPS-400W	GPS	Repair, Spares, Exchange
011-01057-40	GPS-400W	GPS	Repair, Spares, Exchange
011-01060-00	GNS-430W	GPS/Nav/Comm	Repair, Spares, Exchange
011-01060-40	GNS-430W	GPS/Nav/Comm	Repair, Spares, Exchange
063-1007-00	KTR-993	HF Receiver/Exciter	Repair, Spares
064-1009-00	KTR-905	VHF Comm	Repair, Spares, Exchange
064-1009-02	KTR-905	VHF Comm	Repair, Spares, Exchange
064-1023-00	KTR-908	VHF Comm	Repair, Spares, Exchange
064-1023-02	KTR-908	VHF Comm	Repair, Spares, Exchange
064-1029-00	KAC-992	HF Coupler	Repair, Spares
064-1054-30	KY-196A	VHF Comm	Repair, Spares, Exchange
066-1041-00	KXP-755	Transponder	Repair, Spares, Exchange
066-1044-00	KMR-675	Marker Receiver	Repair, Spares, Exchange
066-1047-01	KDF-805	ADF Receiver	Repair, Spares, Exchange
066-1055-70	KMA-24H	Audio Panel	Repair, Spares, Exchange
066-1055-71	KMA-24H	Audio Panel	Repair, Spares, Exchange
066-1066-00	KDM-706	DME	Repair, Spares, Exchange
066-1066-02	KDM-706	DME	Repair, Spares, Exchange
066-1069-00	KDI-572	DME Indicator	Repair, Spares, Exchange
066-1071-00	KXP-756	Transponder	Repair, Spares, Exchange
066-1077-00	KDF-806	ADF Receiver	Repair, Spares, Exchange
066-1077-01	KDF-806	ADF Receiver	Repair, Spares, Exchange
066-1078-00	KNR-634	Nav Receiver	Repair, Spares, Exchange
066-3114-00	IN-812A	Radar Indicator	Repair, Spares, Exchange
066-4007-00	KNR-630	Nav Receiver	Repair, Spares, Exchange
069-1025-25	KX-165	Nav/Comm	Repair, Spares, Exchange
071-1076-00	KDA-697	RMI Adapter	Repair, Spares, Exchange
071-1210-09	KFS-586	ADF Control	Repair, Spares, Exchange
071-1215-40	KFS-598	Comm Control	Repair, Spares, Exchange
071-1216-27	KFS-564	Nav Control	Repair, Spares, Exchange
071-1274-01	KFS-594	HF Control	Repair, Spares, Exchange
071-1378-00	RS-811A	Radar Sensor	Repair, Spares, Exchange
081252-1-10	TDFM-136B	VHF/FM Transceiver	Test, Spares
2587193-43	C-14A	Directional Gyro	Repair, Spares, Exchange
2593379-1	CS-412	Dual Remote Compensator	Test, Spares, Exchange
2593379-001	CS-412	Dual Remote Compensator	Test, Spares, Exchange
2593996-333	TARSYN 333	3-Axis Reference Gyro	Repair, Spares, Exchange
2594484	FX-220	Flux Valve	Test, Spares, Exchange
4000831-0103	RT-1401B	Radar Transceiver	Repair, Spares, Exchange
4000831-0103	RT-1401B	Radar Transceiver	Repair, Spares, Exchange
4001670-2511	IN-2025A	Radar Indicator	Repair, Spares, Exchange
4001670-2513	IN-2025B	Radar Indicator	Repair, Spares, Exchange
4014267-902	RA-235	Radio Altimeter Indicator	Repair, Exchange
4019286-901	VG-14H	Vertical Gyro	Spares, Exchange
4020936-903	TARSYN H	3-Axis Reference Gyro	Spares, Exchange
453-5001	C406-2HM	ELT	Repair, Spares
453-5003	C406-1HM	ELT	Repair, Spares
453-5061	C406-NHM	ELT	Repair, Spares
A301-6W		Audio Control	Repair, Spares, Exchange
S1820502-04	406AP-H	ELT	Repair, Spares